

Lab 2: Clocks and Timers

Instructor's Guide

Lab Introduction

This lab introduces basic concepts of synchronous circuitry and clocks along with one synchronous component: timers. It would be a good idea to cover synchronous circuits in more detail outside of the lab in a lecture, as the topic is too complex to teach in one lab session.

Instructor Review

Part A

The schematic is provided in its entirety and the code section simply requires initialization code for the timer. Just follow the testing instructions in Part 3 of the procedure. Note that Part B of the procedure does not remove functionality of Part A, so a review of Part A can be delayed if desired.

Part B

The schematic for this part is also provided in its entirety. However, this time the code is fully up to the student to write. Here is a sample firmware solution:

```
#include "stdio.h"
#include <project.h>

#define TRUE 1
#define FALSE 0
#define STOPWATCH_FREQ 10000

asm (".global _printf_float"); //adds ~8000 bytes to the program

int main()
{
    //Set to TRUE if the stopwatch has started, else FALSE
    uint8 started_b = FALSE;
    //Temporary storage for status register
    uint8 reg;
    //Capture/counter read value
    uint32 capture;
    //Capture/counter converted to seconds
    float seconds;
    //Temporary string for sprintf to use
    char tstr[16];

    //Start all components and init display
    SecondTimer_Start();
    Stopwatch_Start();
}
```

```

Display_Start();
StopwatchStart_Read();
Display_Position(0, 0);
Display_PrintString("Stopped");
for(;;)
{
    if(!started_b)
    {
        //If the stopwatch isn't known to have started yet,
        //see if the start button has been pressed. If it has
        //been pressed, the stopwatch has started.
        if(StopwatchStart_Read())
        {
            started_b = TRUE;
            Display_ClearDisplay();
            Display_Position(0, 0);
            Display_PrintString("Started");
        }
    }
    else
    {
        //Else, check to see if the stopwatch has been stopped.
        reg = Stopwatch_ReadStatusRegister();

        //If the stopwatch has been stopped, first read the capture
        if(reg & Stopwatch_STATUS_CAPTURE)
        {
            capture = Stopwatch_ReadCapture();
            started_b = FALSE;
        }
        //Else, just read the counter
        else
        {
            capture = Stopwatch_ReadCounter();
        }

        //Convert the capture/counter to seconds and print it
        capture = Stopwatch_ReadPeriod() - capture;
        if(capture != 0)
        {
            seconds = capture / (float)STOPWATCH_FREQ;
            Display_Position(1, 0);
            sprintf(tstr, "%1.4f", seconds);
            Display_PrintString(tstr);
        }

        //If the stopwatch has stopped, reset it
        if(!started_b)
        {
            StopwatchReset_Write(1);
            StopwatchStart_Read();
            Display_Position(0, 0);
            Display_PrintString("Stopped");
        }
    }
}
}

```